Hydraulic Casing Gas Compressor (HCG) Schematic





Power pack provides hydraulic power for the compressor. Control panel governs the operation of the compressor using proprietary algorithms developed by CCI.



Hydraulic fluid supply and return lines pass through a directional valve which directs flow of power fluid to the Left or Right side of compression cylinder. In this example, fluid is being supplied to the Right side and returned from the Left side.

3

5

As the piston is driven from Right to Left (R-L), gas enters the Right side of the compression cylinder through the suction check valve.



At the end of stroke, the piston rod triggers the proximity switch.



6

This reverses the direction of flow of hydraulic fluid through the directional valve. The piston now moves from Left to Right (L-R) and the second part of a single compression cycle starts.



Suction pressure is relayed to the control panel by the suction pressure transmitter.

8

Discharge pressure is relayed to the control panel by the discharge pressure transmitter. The control panel logic ensures that maximum pressure differential for the cylinder is not exceeded. Two additional levels of redundancy exist so that maximum differential pressure is not exceeded: hydraulic system relief valve and PSV set at 400 psi



10

Compressed gas passes through a check valve into the production flowline. A plunger or ball check valve is recommended over a flapper check valve due to the reliability.



- Long stroke and slow cycle rate
- Large check valve port openings

• Gravity assist from horizontal layout and orientation of suction and discharge ports.

http://www.compactcompression.com sales@compactcompression.com